Amiga 500

The Amiga 500 (a.k.a. Amiga OCS/ECS) is a personal computer developed by Commodore. It was released in 1987.

It features a Motorola 6800 CPU; OCS (1.2 & 1.3 models) and ECS (1.3 and 500+ 2.04 models) chipsets. The ECS chipset is capable of switching between PAL/NTSC modes as needed. Outside of that, the ECS chipset didn't offer much enhancement for games, just software.

When available, the Amiga 1200 version of a game is usually superior and preferred.

This system scrapes metadata for the “amiga” group and loads the `amiga500` set from the currently selected theme, if available.

Grouped with the “amiga” group of systems.

Quick reference

- **Accepted ROM formats:** `.adf`, `.uae`, `.ipf`, `.dms`, `.dmz`, `.adz`, `.lha`, `.hdf`, `.exe`, `.m3u`, `.zip`
- **Folder:** `/userdata/roms/amiga500`

Emulators	Accepted ROM formats
fsuae: A500	.adf, .uae, .ipf, .dms, .dmz, .adz, .lha, .hdf, .exe, .m3u, .zip
fsuae: A500+	.adf, .uae, .ipf, .dms, .dmz, .adz, .lha, .hdf, .exe, .m3u, .zip
fsuae: A600	.adf, .uae, .ipf, .dms, .dmz, .adz, .lha, .hdf, .exe, .m3u, .zip
fsuae: A1000	.adf, .uae, .ipf, .dms, .dmz, .adz, .lha, .hdf, .exe, .m3u, .zip
fsuae: A3000	.adf, .uae, .ipf, .dms, .dmz, .adz, .lha, .hdf, .exe, .m3u, .zip
amiberry: A500	.adf, .uae, .ipf, .dms, .dmz, .adz, .lha, .hdf, .exe, .zip
amiberry: A500+	.adf, .uae, .ipf, .dms, .dmz, .adz, .lha, .hdf, .exe, .zip
libretro: puae	.adf, .uae, .ipf, .dms, .dmz, .adz, .lha, .hdf, .exe, .m3u, .zip

BIOS

No Amiga 500 emulator in Batocera needs a BIOS file to run.

ROMs

Place your Amiga 500 ROMs in `/userdata/roms/amiga500`.

Emulators

fsuae

fsuae configuration

Standardized features available to all cores of this emulator: `amiga500.videomode`, `amiga500.ratio`, `amiga500.padtokeyboard`

amiberry

amiberry configuration

Standardized features available to all cores of this emulator: `amiga500.videomode`, `amiga500.ratio`, `amiga500.padtokeyboard`

RetroArch

RetroArch (formerly SSNES), is a ubiquitous frontend that can run multiple “cores”, which are essentially the emulators themselves. The most common cores use the libretro API, so that's why cores run in RetroArch in Batocera are referred to as “libretro: (core name)”. RetroArch aims to unify the feature set of all libretro cores and offer a universal, familiar interface independent of platform.

RetroArch configuration

RetroArch offers a **Quick Menu** accessed by pressing `[HOTKEY]` +  which can be used to alter various things like RetroArch and core options, and controller mapping. Most RetroArch related settings can be altered from Batocera's EmulationStation.

Standardized features available to all libretro cores: `amiga500.videomode`, `amiga500.ratio`, `amiga500.smooth`, `amiga500.shaders`, `amiga500.pixel_perfect`, `amiga500.decoration`, `amiga500.game_translation`

ES setting name `batocera.conf_key`	**Description ⇒ ES option `key_value`**
Settings that apply to all cores of this emulator	
GRAPHICS BACKEND `amiga500.gfxbackend`	Choose your graphics rendering ⇒ OpenGL `opengl`, Vulkan `vulkan`.
AUDIO LATENCY `amiga500.audio_latency`	Audio latency in milliseconds, turn it up if you hear crackles ⇒ 256 256, 192 192, 128 128, 64 64, 32 32, 16 16, 8 8.

ES setting name batocera.conf_key	Description ⇒ ES option key_value
THREADED VIDEO amiga500.video_threaded	Improves performance at the cost of latency and more video stuttering. Use only if full speed cannot be obtained otherwise. ⇒ On true, Off false.

libretro: puae

libretro: puae configuration

ES setting name batocera.conf_key	Description ⇒ ES option key_value
Settings that apply to all systems this core supports	
AMIGA MODEL global.puae_model	Force a specific model and prevent tags detection ⇒ Autodetect (by game name tag) automatic, A500 (512KB Chip + 512KB Slow) A500, A500+ (1MB Chip) A500PLUS, A600 (2MB Chip + 8MB Fast) A600, A1200 (2MB Chip + 8MB Fast) A1200, A4000/040 (2MB Chip + 8MB Fast) A4040, CDTV (1MB Chip) CDTV, CD32 Default (2MB Chip) CD32, CD32 (2MB Chip + 8MB Fast) CD32FR.
CPU COMPATIBILITY global.cpu_compatibility	Help games which are too quick or that have bugs ⇒ Normal normal, More compatible compatible, Cycle-exact exact.
CPU MULTIPLIER (OVERCLOCK) global.cpu_multiplier	Works with 'Cycle-exact' mode and for a few games ⇒ Default by model 0, 3.54 MHz 1, 7.09 MHz (A500 speed) 2, 14.18 MHz (A1200 speed) 4, 28.37 MHz 8, 35.46 MHz 10, 42.56 MHz 12, 56.75 MHz 16.
CPU SPEED (OVERCLOCK) global.cpu_throttle	Ignored with 'Cycle-exact' ⇒ -90% -900.0, -80% -800.0, -70% -700.0, -60% -600.0, -50% -500.0, -40% -400.0, -30% -300.0, -20% -200.0, -10% -100.0, Default 0.0, +100% 1000.0, +200% 2000.0, +300% 3000.0, +400% 4000.0, +500% 5000.0, +600% 6000.0, +700% 7000.0, +800% 8000.0, +900% 9000.0, +1000% 10000.0.

ES setting name `batocera.conf_key`	**Description ⇒ ES option `key_value`**
VIDEO STANDARD `global.video_standard`	Switch frequency and resolution by region ⇒ PAL 50Hz - 288/576px PAL, NTSC 60Hz - 240/480px NTSC.
VIDEO RESOLUTION `global.video_resolution`	Increase the video resolution ⇒ Low 360p `lores`, High 720p `hires`, Super-high 1440p `superhires`.
ZOOM MODE `global.zoom_mode`	Crops the borders to fit various host screens ⇒ Off `none`, Autofit screen `automatic`, minimum `minimum`, smaller `smaller`, small `small`, medium `medium`, large `large`, larger `larger`, maximum `maximum`.
FRAMESKIP `global.gfx_framerate`	Skip frames to improve performance (smoothness) ⇒ Off `disabled`, 1 1, 2 2.
MOUSE SPEED `global.mouse_speed`	Affects mouse speed globally. ⇒ original `100`, 50% `50`, 70% `70`, 120% `120`, 150% `150`, 170% `170`, 200% `200`.
Settings specific to amiga500	
FLOPPY TURBO SPEED `amiga500.puae_floppy_speed`	Removes loading but can add possible glitches/crashes ⇒ Off `100`, On `0`.
2P GAMEPAD MAPPING (KEYRAH) `amiga500.keyrah_mapping`	Keypad to joyport mappings for 2 players ⇒ Off `disabled`, On `enabled`.
WHDLOAD LAUNCHER `amiga500.whdload`	Enable launching pre-installed WHDLoad installs ⇒ Off `disabled`, On `config`.
JUMP ON B `amiga500.pad_options`	Makes second fire button press up ⇒ Off `disabled`, On `jump`.
DISABLE EMULATOR JOYSTICK `amiga500.disable_joystick`	Passes all physical keyboard events for Pad2Key ⇒ Off `disabled`, On `enabled`.
CONTROLLER 1 TYPE `amiga500.controller1_puae`	Select controller type for Amiga P1 ⇒ Retropad 1, CD32 Pad 517, Analog Joystick 773, Joystick 261, Keyboard 259.
CONTROLLER 2 TYPE `amiga500.controller2_puae`	Select controller type for Amiga P2 ⇒ Retropad 1, CD32 Pad 517, Analog Joystick 773, Joystick 261, Keyboard 259.
Settings specific to amiga1200	
FLOPPY TURBO SPEED `amiga1200.puae_floppy_speed`	Removes loading but can add possible glitches/crashes ⇒ Off `100`, On `0`.

ES setting name `batocera.conf_key`	**Description ⇒ ES option `key_value`**
2P GAMEPAD MAPPING (KEYRAH) `amiga1200.keyrah_mapping`	Keypad to joyport mappings for 2 players ⇒ Off `disabled`, On `enabled`.
WHDLOAD LAUNCHER `amiga1200.whdload`	Enable launching pre-installed WHDLoad installs ⇒ Off `disabled`, On `config`.
JUMP ON B `amiga1200.pad_options`	Makes second fire button press up ⇒ Off `disabled`, On `jump`.
DISABLE EMULATOR JOYSTICK `amiga1200.disable_joystick`	Passes all physical keyboard events for Pad2Key ⇒ Off `disabled`, On `enabled`.
CONTROLLER 1 TYPE `amiga1200.controller1_puae`	Select controller type for Amiga P1 ⇒ Retropad 1, CD32 Pad 517, Analog Joystick 773, Joystick 261, Keyboard 259.
CONTROLLER 2 TYPE `amiga1200.controller2_puae`	Select controller type for Amiga P2 ⇒ Retropad 1, CD32 Pad 517, Analog Joystick 773, Joystick 261, Keyboard 259.
Settings specific to amigacd32	
BOOT ANIMATION FIRST `amigacd32.puae_cd_startup_delayed_insert`	Inserts CD during boot animation to prevent loading fail ⇒ Off `disabled`, On `enabled`.
CD TURBO SPEED `amigacd32.puae_cd_speed`	Removes loading but can add possible glitches/crashes ⇒ Off `100`, On `0`.
JUMP ON A `amigacd32.puae_cd32pad_options`	Makes Blue button press Up ⇒ Off `disabled`, On `jump`.
Settings specific to amigacdtv	
BOOT ANIMATION FIRST `amigacdtv.puae_cd_startup_delayed_insert`	Inserts CD during boot animation prevent loading fail ⇒ Off `disabled`, On `enabled`.
CD TURBO SPEED `amigacdtv.puae_cd_speed`	Removes loading but can add possible glitches/crashes ⇒ Off `100`, On `0`.

Controls

Here are the default Amiga OCS/ECS's controls shown on a Batocera Retropad:

Troubleshooting

Further troubleshooting

For further troubleshooting, refer to the generic support pages.

From:
https://wiki.batocera.org/ - **Batocera.linux - Wiki**

Permanent link:
https://wiki.batocera.org/systems:amiga500?rev=1638672223

Last update: **2021/12/05 02:43**