Atari 800

The Atari 800 is a computer developed by Atari. It was released in 1979.

The current emulation of the Atari 800 based family of computers is not complete or fail safe. This wiki article only gives basic instructions so you can run some popular games. The full technical background on these issues can be found in this article: Atari 8-Bit Guide (Raph Koster). The script mentioned in these pages is **not** integrated into Batocera yet, so you are stuck with the manual fixes until then.

This system scrapes metadata for the “atari800” group and loads the `atari800` set from the currently selected theme, if available.

Quick reference

- **Emulator:** RetroArch
- **Core:** libretro: atari800
- **Folder:** `/userdata/roms/atari800`
- **Accepted ROM formats:** `.rom`, `.xfd`, `.atr`, `.atx`, `.cdm`, `.cas`, `.car`, `.bin`, `.a52`, `.xex`, `.zip`, `.7z`

BIOS

No Atari 800 emulator in Batocera needs a BIOS file to run.

There are subtle differences in machine type between the different Atari Computers, including different version of the OS (BIOS). Some games will crash unless you manually select a different BIOS.

This is conflicting information, which is correct?

ROMs

Place your Atari 800 ROMs in `/userdata/roms/atari800`.

Multi-Disk games can only be used with an internal menu of the emulator. Playlists and RetroArch features for these games are not supported.

Emulators

RetroArch

RetroArch (formerly SSNES), is a ubiquitous frontend that can run multiple “cores”, which are essentially the emulators themselves. The most common cores use the libretro API, so that's why cores run in RetroArch in Batocera are referred to as “libretro: (core name)”. RetroArch aims to unify the feature set of all libretro cores and offer a universal, familiar interface independent of platform.

RetroArch configuration

RetroArch offers a **Quick Menu** accessed by pressing `[HOTKEY]` +  which can be used to alter various things like RetroArch and core options, and controller mapping. Most RetroArch related settings can be altered from Batocera's EmulationStation.

Standardized features available to all libretro cores: `atari800.videomode`, `atari800.ratio`, `atari800.smooth`, `atari800.shaders`, `atari800.pixel_perfect`, `atari800.decoration`, `atari800.game_translation`

ES setting name `batocera.conf_key`	**Description ⇒ ES option `key_value`**
Settings that apply to all cores of this emulator	
GRAPHICS BACKEND `atari800.gfxbackend`	Choose your graphics rendering ⇒ OpenGL `opengl`, Vulkan `vulkan`.
AUDIO LATENCY `atari800.audio_latency`	Audio latency in milliseconds, turn it up if you hear crackles ⇒ 256 256, 192 192, 128 128, 64 64, 32 32, 16 16, 8 8.
THREADED VIDEO `atari800.video_threaded`	Improves performance at the cost of latency and more video stuttering. Use only if full speed cannot be obtained otherwise. ⇒ On `true`, Off `false`.

libretro: atari800

libretro: atari800 configuration

ES setting name `batocera.conf_key`	**Description ⇒ ES option `key_value`**
Settings specific to atari800	
ATARI SYSTEM `atari800.atari800_system`	Choose what Atari System to emulate ⇒ 400/600XL/800 (48K) (OS B) `400/800 (OS B)`, 800XL/1200XL/XEGS (64K) `800XL (64K)`, 130XE (128K) `130XE (128K)`, Modern XL/XE (320K CS) `Modern XL/XE(320K CS)`, Modern XL/XE (576K) `Modern XL/XE(576K)`, Modern XL/XE (1088K) `Modern XL/XE(1088K)`.
VIDEO STANDARD `atari800.atari800_ntscpal`	Switch frequency and resolution by region ⇒ NTSC NTSC, PAL PAL.

ES setting name `batocera.conf_key`	Description ⇒ ES option `key_value`
SIO ACCELERATION `atari800.atari800_sioaccel`	Speeds up file loading (a few games will not load) ⇒ Off `disabled`, On `enabled`.
HI-RES ARTIFACTING `atari800.atari800_artifacting`	Artificial color filters to mimic actual hardware ⇒ Off `disabled`, On `enabled`.
INTERNAL RESOLUTION `atari800.atari800_resolution`	Enables alternate resolutions for some games ⇒ 336×240 `336×240`, 320×240 `320×240`, 384×240 `384×240`, 384×272 `384×272`, 384×288 `384×288`, 400×300 `400×300`.
Settings specific to atari5200	
JOYSTICK HACK (FOR ROBOTRON) `atari5200.atari800_opt2`	Treats the second analog stick as joystick 2 ⇒ Off `disabled`, On `enabled`.

Controls

Analogue joysticks are supported only via hardcoded mouse inputs (bypassing RetroPad and default controls). The analog sticks of gamepads are NOT supported. This makes some games unplayable unless you connect a mouse.

Sure that it's not possible to remap them?

Here are the default Atari 800's controls shown on a Batocera Retropad:

Troubleshooting

My game is black and white!

Many (US) games look wrong because they use specific video artifacts to generate colors on NTSC TVs but look black and white in emulation, unless you set specific parameters.

What parameters?

Game is not booting

Most ROM sets are in a format that requires one additional input at the start of a ROM. Sometimes the selection screen is not visible making it look like the emulator crashed.

So what buttons are common to try to get out of this?

Further troubleshooting

For further troubleshooting, refer to the generic support pages.

From:
https://wiki.batocera.org/ - **Batocera.linux - Wiki**

Permanent link:
https://wiki.batocera.org/systems:atari800?rev=1638666444

Last update: **2021/12/05 01:07**